Co-Mo Connect
Powered by Co-Mo Electric Cooperative

AMAZON FIRE STICK REMOTE GUIDE

Power Button – Turns the tv on/off.

Microphone – allows you to tell the firestick to open app. Currently not supported while in Halo.

Navigate Up/Down – allows you to move up when in menus or change channels in Halo.

Navigate left/right – allows you to move left/right when in menus. Can also fast forward or rewind in Halo.

Home – Takes you back to the home screen on the firestick.

Back – brings up your last viewed channels

Menu – takes you back to the main menu screen in halo.

Rewind

Pause/Play

Fast Forward

Volume Up

Volume Down

Mute

Questions? Contact our technical support at 888-256-9575.